

Setting Alarm and Auto Off

This device is programmed with three user configurable settings:

ALSET - The **percentage** of full load that the audible alarm will sound

AOSET - The amount of minutes without a button being pressed before the device will automatically switch off. This feature is disabled if set to 0

OLOAD - The amount of times the device has been overloaded since last calibrated. (Read only)

To change these settings please follow the flowchart below:

