

## Radiolink Battery Reset


Once the battery in the radiolink is low a latching error is activated 'rem error'.

Even if the Radiolink batteries are changed this error flag will remain until reset - the Radiolink will function normally even with this flag activated.


To reset the error:

Press and hold  &  keys for 3 seconds

an error number will appear (normally '1')

Press  display will show 'reset'

Press  display will show 'finished'

Press  display will return to normal mode minus the error flag.