
Radiolink vT24 Pairing Instructions

Occasionally the loadcell and the handheld display will loose its pre-programmed connection referred to in this guide as 'pairing'. When this happens the display on the handheld will look like this:





4) As soon as 'Pairing' displays refit the loadcell batteries, pairing will automatically occur and you should

see a load displayed. Please note the 'pairing' mode is only held for 10 seconds, if you do not refit the

batteries within this period then you will need to start again at step one.