

# Quick Start Guide



-  Power On/Off
-  Peak Hold On/Off / Reset
-  Weight Units  
*Tonne > Kilonewtons  
> Kilogrammes > Pounds*
-  Tare

## AVAILABLE KEYS

### BACKLIGHT ON



### PAIRING TO A CABLED LOAD CELL

(If purchased separately)



Then press

### TO END PAIRING



### CONFIGURATION MENU



SCROLL UP



SCROLL DOWN



ENTER

### FULL HHP MANUAL DOWNLOAD



# HHP

v1.00  
Part No:  
SU6071